

UTV PLOW ORDERING GUIDE



MODEL	LIFT FRAME	MOLDBOARD
VUT65	16018000	16020704
MUT60	16018100	16020404
MUT68	16018100	16020410

AVAILABLE MOUNTS

MFR	YEAR	MODEL	VUT - 16018000 MUT - 16018100
Bobcat	2007-2010	2200/2300/3400	16067300
	2011+	3400	16067210
Case	2008+	Scout/Scout XL	16067300
Club Car	2007+	XRT	16067300
Husqvarna	2007+	HUV4421	16067300
John Deere	2011+	Gator XUV	16067800
Kubota	2009-2013	900/1140RTV	16067100
	2014+	X900/X1100/X1120	
Mahindra	2008+	2015+ mPact	16067400
New Holland	2008+	Rustler 120/125	16067300
Polaris	2012+	Ranger XP900	16067720
	2009-2012	Ranger	16067710

This guide is for reference only and does not guarantee fit on all vehicles as shown